
SMOKI USA - MAXI GRILL MAINTENANCE CHECKLIST

Block 1: Turn OFF and Drain Dirty Water

1. Power Down

- ☐ Remove front stainless steel panel
- ☐ Turn red power dial on white electrical box to OFF
- ☐ Verify unit is completely off (no pump pressure, machine noise)

2. Stop Water

- ☐ Find fresh water gauge
- ☐ Turn water supply to OFF (horizontal)
- ☐ Confirm water pressure gauge drops to 0

3. Drain Tank

- ☐ Unscrew black knobs to remove maintenance panel
- ☐ Turn red drain lever to horizontal to drain water tank
- ☐ Wait until tank is completely empty

Block 2: Wash & Check Components

1. Remove Filters

- ☐ Slide out top filters
- ☐ Examine filters for residue/need for deeper cleaning (if material cannot be washed off of filters with hose, they will need to be washed separately with a more powerful hose and soapy water)



(844) GO SMOKI / (844) 467 6654 | info@smokiusa.com
www.smokiusa.com

2. Clean Tank

- ☐ Get yellow cleaning hose
- ☐ Place hose inside unit
- ☐ Turn on hose tap knob (below fresh water knob)
- ☐ Wash all tank walls and filters thoroughly
- ☐ Turn off hose and put it back

Block 3: Refill Fresh Water and Turn ON

1. Close Everything Up

- ☐ Turn red drain lever to vertical (closed)
- ☐ Turn water supply to ON
- ☐ Put maintenance panel back on
- ☐ Screw in all 4 black knobs

2. Power Up

- ☐ Turn red power dial to ON
- ☐ Wait for tank to fill
- ☐ Check pump starts automatically
- ☐ Verify normal operation

Contact: INFO@SMOKIUSA.COM



Pre-Maintenance Form

Pre-Maintenance Form

Date: _____

Unit Location: _____

Maintained by: _____

Current Readings:

- Water Pressure: _____ PSI
- Last Maintenance Date: _____
- Hours Run Since Last Service: _____
- Any unusual noises or operation? Yes [] No []

Post-Maintenance Form

Post-Maintenance Form

Final Readings:

- Water Pressure: _____ PSI
- Filter Condition: Clean ☐ Replaced ☐
- Unit Operation: Normal ☐ Issue ☐

Notes: _____

Next Maintenance Due: _____

Quarterly Deep Clean Due: _____